

MDT3700 Quick Start Install Guide

If you have any questions, please contact BSM support at **1-888-776-3333** then press **1**.

Hours: Monday – Friday, 8:00 AM – 9:00 PM EST

⚠ WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

Kit Contents

The MDT3700 kit includes the following:



Installation Process

1. Attach the MDT cradle **(B)** to the suction cup arm mount **(E)** using the 4 silver screws **(D)**:
2. Attach the Micro USB end of the USB power cable **(F)** to the cradle:



3. Attach the suction cup arm mount to the windshield, using the lever to engage suction:



IMPORTANT: Ensure the windshield surface is clean before mounting the suction cup.

4. Power and data connections:
A) Standard Power Connection: Plug in the USB power cable (F) to the USB cigarette lighter adapter (G), and then plug the adapter into the vehicle's cigarette lighter:



- B) (Optional) Power and data connection:** If this option is purchased, an **IOX-USB cable** will be included in the kit. In this case, the MDT3700 must be powered through the Geotab GO Device via the IOX-USB cable as shown here:



(Optional) To permanently fasten the MDT3700 to the cradle, fasten the two medium black screws (C) through back of the cradle into the back of the MDT:

IMPORTANT: You should only do this if it is requested by the fleet manager in writing.

